

# PIR MP .ALERT—A9

## **Function introduction :**

- A, When the body is near, it will automatically start the alarm;
- B, The highest sensitivity in the range of 4-5 meters;
- C, Put the alarm cat or paste in a certain height, away from the body within 5 meters within the angular range 120 ° left and right, as long as people or animals, swaying back and forth in a very short time, induction start.
- D. Connectivity can listen to a location within 15 meters of the situation, the sound is very clear.

## **using methods:**

- A) turning on: open the deck lid, insert the SIM card follow the instructions in Figure deck automatically boot.
- B) number binding: after 15 seconds calling from mobile phone and other communication tools, It will connect automatically. When you hear voice call, the binding succeeds. This operation is very simple.

C) while human body moving back and forth passing the sensor, the product will call the binding number.

**Remote-control setting:**

- 1) Send "0000" to the SIM card number after a successful turn off this feature;
- 2) Send "1111" is open induction.

**Operating frequency:**

850MHZ, 900MHZ, 1800MHZ, 1900MHZ;

**Standby time:**

For body sensing:5-7days not for body sensing:15-20days.

**product specification:**

A, product size: 4.50\*3.0\*1.40 cm

B, working current: below 10 mA

C. **idle current : below 0.05 mA**

C, sensitivity: 5-8m center angle 90°